

## Key Points for RSA Coatings Over Dintel

- Multiprime is a key component to the overall system and must be applied to all surface areas to be coated.
- Assess the area to be coated for total thickness required to make good.
- If pack-outs of greater than 4mm are required, a heavy slurry coat of RSA Masonry Render with straight Render Bond will be required and pack out with a 50/50 mixture of Set & prep and Masonry Render.
- If pack-outs of greater than 8-10mm are required. The Dintel must be cut off and general rendering practise over formwork must be applied.
- There is very little suction or next to none on Dintel. It is recommended that a tight coat of flexirender is applied first and allowed to touch dry prior to applying over 1mm thick. This first coat will help with suction and drying time.
- Ensure that Control Joints at a minimum of 10mm are cut and applied at all slab and different substrate junctions