



Key Points for RSA Set & Prep

- When using as a patching compound for F.C Sheet, The fibreglass reinforcing mesh must be bedded into the product rather than direct fix with self adhesive mesh.
- It is normal for Set & Prep to have a hairline crack visible prior to application of an acrylic texture.
- For this reason a minimum film build of 2mm in total texture thickness is required.
- The flexibility of the acrylic coatings is critical to the success of this system.
- When mixing Set & Prep, allow to sit for around 5 minutes and re-agitate to increase pot life.
- When applying Set & Prep to painted surfaces a minimum thickness of 2mm “scratch coat” is required for maximum adhesion.
- A 2mm tiler’s notch trowel is ideal for application of Set & Prep over painted surfaces.
- Apply the 2nd coat of RSA render over the scratched surface whilst green but firm to touch.
- The base coat will give some suction to the freshly applied render and form a mechanical key through the entire coating system.